



Installation Manual Of Cross Bar For JK Wrangler 4dr/ JL Wrangler 4dr & JT Gladiator. JK Wrangler 2dr/ JL Wrangler 2dr.

Parts List



Instructions





Jeep Wrangler JK 4dr Hard-top

Front Crossbar = 1272mm
Rear Crossbar = 1291mm

A = 300mm (11 13/16)

B = 500mm (19 11/16)





Jeep Wrangler JK 2dr Hard-top

Front Crossbar = 1256mm

Rear Crossbar = 1283mm

A- B = 480mm (18 7/8)





Jeep Wrangler JL 4dr Hard-top

Front Crossbar = 1272mm
Rear Crossbar = 1291mm


A = 300mm (11 13/16)

B = 500 (19 11/16)



Note:

- Front crossbar can be positioned at rear.
- La barra transversal delantera se puede colocar en la parte trasera.





Jeep Wrangler JL 2dr Hard-top

Front Crossbar = 1256mm

Rear Crossbar = 1283mm

A- B = 480mm (18 7/8)



Jeep Wrangler Gladiator JT 4dr Hard-top

Front Crossbar = 1272mm
Rear Crossbar = 1291mm

A = 300mm (11 13/16)

B = 500 (19 11/16)

